


ULTRA-LINEAR

Installation Instructions

General Safety Information

- Installation, commissioning and maintenance only by qualified electrician.
- Never perform any work on the luminaire with voltage applied. Danger to life due to electric shock!
- Electric connection must be appropriate according to all applicable standards and other national and international safety and accident prevention regulations.
- Damaged luminaires must not be operated.
- Observe and retain safety instructions and mounting instructions
- No liability is accepted for damages resulting from improper use.
- Use genuine parts only for repair.




Instructions



ULTRA-LINEAR

Installation Instructions

Instructions Continued



This product contains a light source of energy efficiency class . (4000K)

This product contains a light source of energy efficiency class <C>. (3000K, 3000/4000K)

Instructions for Replacement

- Open the end cap and remove the diffuser;
- Screw out the fixing screws on PCB board and LED driver;
- Replace the LED module and driver with new one;
- Put back the diffuser and lock the end cap.

